Mini Stereo Speaker

MUSIC ANGEL friendz

Freedom to listen and share your favourite music

Model JH-MD04E

Music Angel Friendz is a mini stereo speaker with a digital amplifier and a rechargeable battery with playback time of 10 to 50 hours. It is built into a stylish aluminium frame. Play from any digital device with a 3.5 mm jack/headphone port.

Music Angel Friendz gives you freedom to listen and share your favourite music, digital radio, podcast, video, TV and games from anywhere and anytime. Or even use it for your lecture presentations or phone and Skype conferences.

Make Friendz by connecting to other Friendz. We have made a LINE OUT port so you can connect to as many Friendz as you want.

Have great fun on the beach, in parks, at school, on travel, at work, in your car, at conferences, hotels, holidays – only your fantasy puts a limit to its use.

LED indicator!

- **Blue**: Speaker is powered on.
- **Red**: Speaker battery is charging. LED turns off when battery is fully charged.
- **Purple**: Speaker is charging and powered on.

PLAYING!

Turn the speaker power on. The LED illuminates in blue. Connect the mini USB plug to the speaker LINE IN/5V. Connect your MP3 player, phone or any digital device to the speaker by using the 3.5 mm headphone jack. Once connected, control your audio volume and navigate your content on your device. For more ideas on how to use the speakers, please follow our website www.musicangel.no.

...FRIENDZ to FRIENDZ!

Connect the mini USB plug to the second speaker LINE IN/5V. Connect the 3.5 mm headphone jack into the LINE OUT of the first speaker. Continue to hook up as many speakers as you want. When using many Friendz speakers in a line, it is advised to use the 20 cm Friendz cable.

Charging

Connect a PC or any USB charger (DC 5V, 0.4-1.0 A) to the speaker by using the USB plug on the retractable cable. Connect the mini USB plug to the speaker LINE IN/5V. LED illuminates in red if speaker is turned off. LED illuminates in purple if speaker is on. LED (red/purple) turns off when battery is fully charged.

Problem solving

•Check that the 3.5 mm headphone jack is connected correctly.

•Check if the battery is fully charged.

•Make sure that the power switch on the speaker is set to the ON position.

If you are unable to solve the problem by following these steps, please contact online help at (www.musicangel.no) or consult your dealer. Never try to open the speaker, as this will void the guarantee.

Safety information

- The speaker should not be exposed to dripping or splashing or placed in a condensing environment.
- Do not place the unit close to sources of open flame. The battery should not be exposed to excessive heat.
- Please dispose of the unit in an environmental friendly way, due to the lithium battery embedded. For questions, please contact your local authorities about where to dispose the unit.
- Use care when connecting several Music Angel Friendz together, or playing a unit at high volume. The speaker is capable of producing a high sound level. Exposure to loud music over time might lead to hearing loss or impairment.

Technical specifications

- Output power: RMS 6W (3W+3W) THD=10%
- Frequency response: 150-18000HZ (±3dB)
- Magnetic resistance: 4Ω
- Power supply: USB source DC-5V - 1000mA
- Speaker dimension: 75 x 50 x 52mm
- Weight: 150 gram

More Information

For more and updated information, please visit the Music Angel Europe's website at musicangel.no.

The manufacturer reserves the right to change the specifications without notice.

Made in China. © 2011 by Music Angel Europe AS
P.O. Box 52,
N-4801 Arendal
Norway

The package contains

- Music Angel Friendz stereo speaker
- Retractable cable 80 cm
- Friendz cable 20 cm
- User manual
- Jewellery bag